


## 1018\_3B Mechanical Drawing





## 1018\_3B Enclosure Mechanical Drawing





## Mounting Dimensions





You can mount this device by removing the top half of the enclosure and using M2 bolts and nuts to secure it with the PCB still inside, and then snap the top of the enclosure back on.

Or, you can leave the enclosure assembled and use M2.3 self-tapping screws from underneath.